

## Down340 for customers – Ethernet communication

(29.10.2012 / MTE-FBA)

The tool can be used with EMH devices for:

- Firmware download
- Communication via ASCII commands in command line or by call of macros (Options)
- Screen shots of the actual display (\*.BMP pictures) with screen grabber function (Options)

### Example settings for Ethernet communication with PWS3.3

#### PWS3.3 Ethernet network settings

Reference Power Quality Data Base

**DHCP** 166.166.1.207 ... 166.166.1.209

**IP** 166.166.1.97

**MASK** 255.255.255.0

**Gway** 255.255.255.0

**UDP** 12345 **TCP** 49152

MAC 00:1f:58:00:01:4b

1.0GB 16:59:14 29.10.2012

#### Down340 TCP/IP settings

Down340 via TCP 166.166.1.97:49152

Y Show Y

Log ☒ t ☐ C:\

via TCP 166.166.1.97 49152

VER1=PWS3.3 #37522<CR>  
VER2=U2.04<CR>  
VER3=AC0<CR>  
VER4=19.09.2012<CR>

V1.26 B0003

Ende Options START